

TILE CUTTER

Model No 284201

Thank you for purchasing **TACTIX** Tile Cutter.

Both 284203 and 284201 tile cutters are ideal for professional and DIY users alike.

Cuts ceramic tiles up to 400 mm (16 in.) in length, and 10 mm (3/8 in.) thick.

Please read these instructions thoroughly before use. This will ensure not only the safety of both yourself and those around you, but also accuracy of operation and long and trouble free service free service from your Tile Cutter.

STRAIGHT CUTTING

WARNING! ALWAYS wear protective eye goggles when using the Tile Cutter

- First, thread the handle into the slide housing as indicated in the illustration and tighten.
- Place the tile on the work table, with the line to be scored exactly in line with the zero mark on the scale. Hold the tile firmly in place with your left hand, as shown.
- Raise the handle and draw the slide back past the edge of the tile, then lower the handle so that the tungsten carbide scoring wheel comes into contact with the leading edge of the tile.
- Apply firm pressure (not too heavy) down on to the handle while pushing forward smoothly and evenly in the direction of the arrow so that the tile is scored along its complete length.
- Raise the handle and WITHOUT MOVING THE TILE, reposition the slide so that the breaker bars are approximately on the edge of the tile

IMPORTANT: the scoring wheel should NOT be in contact with the tile.

Pressing down on the handle again will cause the tile to break.

• NOTE: It is necessary to score the tile ONCE ONLY.

